

1029117

Axle-back 3" dual straight pipe performance kit w/s/s tips, 2015 Ford Mustang GT 5.0L

Note, this is a very aggressive sounding exhaust system and may not be legal on public roads in many areas your car may be driven. Check local laws for legality of this system. Recommended for race use only.

Kit Includes:

- | | |
|---|--|
| 1) passenger side tail pipe # 1029112 | 1) driver side tail pipe # 1029111 |
| 1) passenger side rear tail pipe w/s/s tip #1029118 | 1) driver side rear tail pipe w/s/s tip #1029119 |
| 2) # a25af accuseal clamps | 2) # a30af accuseal clamps |

DANGER WARNING: Should the purchaser decide to install this exhaust product at home, be warned that pleasure car or light duty truck/van "bumper" jacks are intended for emergency use only. The use of frame contact jack stands in conjunction with a floor jack as main support is highly recommended to minimize accidental dropping of a vehicle while the installation proceeds.

Limitation of liability--Disclaimers: The regulation of emissions production, noise levels and safety standards is undertaken by the federal government, each of the fifty state legislatures, and by many local municipalities, towns and counties.

The manufacturer makes no warranties of merchantability, of fitness for a particular purpose, or that its products are approved for general use, or that its products comply with laws, regulations or ordinances in the states where they may be sold to the ultimate purchaser, the consumer.

The entire risk as to the conformity of this product in any such state and as to repair, should the product prove to be defective or non-conforming, is on the retail purchaser, the buyer, the ultimate consumer of such product and it is not upon the seller, distributor, or manufacturer.

In this connection, retail purchaser, the buyer, the ultimate consumer assumes the burden of the entire cost of any and all necessary service, alterations, and or repair.

The foregoing statement limits the liability of the manufacturer.

Instructions:

NOTE: DO NOT TIGHTEN ANY BOLTS OR CLAMPS UNTIL THE LAST STEP!!

- 1) Disconnect the battery (this will allow the vehicles computer to reset and read the new exhaust system).
- 2) Support the vehicle in a safe manner, using a shop hoist or frame contact jack stands on a level surface. Remove the o.e. mufflers 6" after the factory resonator. To do so, you will need to cut the oe tail pipes. We recommend using a reciprocating saw, cutoff wheel, or hacksaw.
- 3) For the driver side, see pictures below, and measure approximately 6" after the welds on the factory resonator (it is approximately 30.5" from the hanger on the driver side and approximately 30" on the passenger side, measure forward) make both cuts 6" from this weld for both the driver and passenger side, pic below. You may want to remove the entire exhaust from the clamps in front of the resonator to the rear to make your cuts, as shown below. If so, you will need to remove, and re-attach when installing again, the o.e. hanger mounts are just behind the rear differential by unbolting and reinstalling. You can attach the o.e. rubber hanger mounts to the wire hook on the tail pipes at this time, these will need to be bolted back up to the same location upon installation of the tail pipes.
- 4) Install the driver side tail pipe to the driver side outlet of the o.e. resonator using a 2.5" clamp, reattach the o.e. hanger setup just after the rear axle.
- 5) Repeat step 3) and 4) for the right (passenger) side. The cut length on this side is 30" from the hanger, see pictures below.
- 6) install the driver side rear tail pipe with tip to the driver side tail pipe, and connect the wire hanger to the o.e. rubber hanger mount above, using a 3" clamp to secure where the two pipes join.
- 7) repeat step 6) for the passenger side.
- 8) Check for clearance of the frame, body, suspension members, and of all brake and fuel lines. When you are satisfied with how the mufflers hang and how the tips are positioned, tighten the clamps, torque the accuseal clamps to 35-45 ft. lbs. Reconnect the battery.

BUILD SHEET FOR: 3" MUSTANG AXLE-BACK straight pipe kit

PART #'S: 1029117

- _____ 1) HARDWARE KIT
- _____ 1) passenger side tail pipe # 1029112
- _____ 1) driver side tail pipe # 1029111
- _____ 1) passenger side rear tail pipe w/s/s tip #1029118
- _____ 1) driver side rear tail pipe w/s/s tip #1029119

INSPECTED BY: _____

DATE: _____

INSPECTED BY: _____

DATE: _____