

Part # 1001353 w/stainless steel angle cut tips Part # 1001352 w/stainless steel blunt cut tips

Part # 1001852 w/painted blunt cut tips

Kit fits '94-'95 full-size GM 1/2 & 3/4 ton pickup, 2WD & 4WD, all wheel bases, w/4.6L V-6, 5.0L & 5.7L V-8, with 2-3/4" exhaust at the converter. This kit is a cat-back exhaust system.

Heartthrob Exhaust--Litchfield, MN www.heartthroboxhaust.com

DANGER WARNING: Should the purchaser decide to install this exhaust product at home, be warned that pleasure car or light duty truck/van "bumper" jacks are intended for emergency use only. The use of frame contact jack stands in conjunction with a floor jack as main support is highly recommended to minimize accidental dropping of a vehicle while the installation proceeds.

Limitation of liability--Disclaimers: The regulation of emissions production, noise levels and safety standards is undertaken by the federal government, each of the fifty state legislatures, and by many local municipalities, towns and counties.

The manufacturer makes no warranties of merchantability, of fitness for a particular purpose, or that its products are approved for general use, or that its products comply with laws, regulations or ordinances in the states where they may be sold to the ultimate purchaser, the consumer.


The entire risk as to the conformity of this product in any such state and as to repair, should the product prove to be defective or non-conforming, is on the retail purchaser, the buyer, the ultimate consumer of such product and it is not upon the seller, distributor, or manufacturer.

In this connection, retail purchaser, the buyer, the ultimate consumer assumes the burden of the entire cost of any and all necessary service, alterations, and or repair.

The foregoing statement limits the liability of the manufacturer.

HARDWARE KIT:

- | | | |
|---|---------------------------------|--|
| 2) 3" clamps | 5) 2-1/4" clamps | 1) long welded hanger clamp 2-1/4" #2927 |
| 1) short welded hanger clamp 2-1/4" #2928 | 1) 5/16" x 1" bolt | 1) 5/16" nut |
| 1) fomed flange | 2) 3/8" x 1-3/4" bolts | 2) 3/8" nuts |
| 2) 3/8" lock washers | 1) 3" welded hanger clamp #2954 | |
| 1) 5/16" lock washer | 1) fender washer | 1) BR91930 swinger hanger |
| 2) muffler tips—painted--#8433518 | 1) right tail pipe--#1001356 | 1) 3" id/od extension pipe--#2008351-5 |
| 1) y-pipe--#0030031 | 1) left tail pipe--#1001355 | 1) 3" front extension pipe--#2008351-2 |



Kit #1001353, #1001352, #1001852

INSTRUCTIONS:

NOTE: do not tighten any clamps or nuts and bolts until the last step!! Before cutting any pipes it is a good idea to lay out all the included pipes along side the vehicle and get a good idea of how the pipes will hang on the vehicle. Please read the instructions fully and thoroughly before you begin.

1) Remove the exhaust system at the flange behind the converter leaving only the original y-pipe, rubber mounts for the hangers, and the catalytic converter on the truck.

NOTE: The flanged front pipe will need to be cut to fit the regular cab models. This pipe fits extended cab short box models without cutting. For extended cab long box models, an additional pipe is included with an extra clamp. These pieces are not needed on the other three models.

2) Slip the flanged front pipe into place and slide the flange on the pipe (flat side first) to the converter flange. Install the 3/8" hardware (or use the original) to connect the new and old flanges.

For those with regular cab short box models, cut 23" off the flanged front pipe from the end that is 3" O.D. For those with regular cab long box models, cut 10" off the flanged front pipe from the end that is 3" O.D. For those with extended cab short box, go to step 3). For those with extended cab long box, add the 17" long extension pipe and attach to the flanged front pipe using a 3" clamp.

3) Install the 3" hanger clamp to the flanged front pipe at the front O.E. rubber mount.

4) Install the y-pipe to the extension pipe (the leg with the bend goes to the passenger side). Attach with a 3" clamp included in the hardware kit provided.

5) Install the right tail pipe (it has 5 bends) making sure that you have at least 1/2" of clearance from the shock. Using the existing rubber hanger mounts, install the 2-1/4" welded hanger clamps to the rubber mounts and clamp to the right tail pipe. Attach a 2-1/4" clamp to the inlet of the left tail pipe, where the right tail pipe and the y-pipe connect. **NOTE:** do not tighten at this time, as you may want to cut the rear of the tail pipes to your preferred length. Trim to your desired length by holding up a tip and marking the required amount to cut off.

6) Install the muffler tip onto the right tail pipe. Use a 2-1/4" clamp to secure the tip to the tail pipe.

7) Install the left tail pipe (4 bends) using a 2-1/4" clamp, making sure that you have clearance between the rear brake line (bend bracket to the front if necessary), shock, and spare tire. The left tail pipe crosses over the top of the drive shaft and then crosses over the top of the axle. It will be necessary to gain the proper clearance between the left tail pipe and the brake and breather lines by tying the lines away using a wire or cable tie. Again, you may want to trim the pipe to length, so do not tighten the clamp yet.

8) Locate the mounting hole (or drill if one is not present) directly above the rear of the left tail pipe and mount the BR91930 swinger hanger to the frame using a 5/16" x 1" bolt, nut, lock washer, and fender washer. Make sure the distance from the frame to the top of the pipe is equal to the hanger on the right side. Clamp the tail pipe to the hanger using a 2-1/4" clamp. As in step 3), trim the left tail pipe to your desired length. Make sure the tail pipe is cut to the same length as the right tail pipe.

9) Mount the other muffler tip to the left tail pipe using a 2-1/4" clamp.

10) Tighten all clamps, nuts, and bolts. Check for leaks and for clearance of all brake and fuel lines, and for clearance of all chassis and frame components. We recommend tack welding the joints (not necessary though).

BUILD SHEET FOR: DEEP TONE DUAL KITS
PART #1001353, 1001352, 1001852

- _____ 2) muffler tips— s/s angle, s/s blunt, painted blunt
- _____ 1) right tail pipe--#1001356
- _____ 1) 3” id/od extension pipe-#2008351-5
- _____ 1) y-pipe--#0030031
- _____ 1) left tail pipe-#1001355
- _____ 1) 3” front extension pipe-#2008351-2
- _____ 1) hardware kit

INSPECTED BY: _____

DATE: _____

INSPECTED BY: _____

DATE: _____

BUILD SHEET FOR: DEEP TONE DUAL KITS
PART #1001353, 1001352, 1001852

- _____ 2) muffler tips— s/s angle, s/s blunt, painted blunt
- _____ 1) right tail pipe--#1001356
- _____ 1) 3” id/od extension pipe-#2008351-5
- _____ 1) y-pipe--#0030031
- _____ 1) left tail pipe-#1001355
- _____ 1) 3” front extension pipe-#2008351-2
- _____ 1) hardware kit

INSPECTED BY: _____

DATE: _____

INSPECTED BY: _____

DATE: _____